#### **Daily Measurements**

**Take one measurement** each day unless advised otherwise by your healthcare provider. The LED will turn RED each morning and then turn GREEN once a measurement has been successfully transmitted.





Measurement Needed

Measurement Successful

# **Power Your Gateway**

**Plug your Gateway into a power outlet** with the provided power cord and wait until the LED on the Gateway turns RED.





For further assistance, please visit Tenovi.com/support.




© 2025 Tenovi Co.

All rights reserved. Republication, duplication or modification in whole or in part is prohibited without prior written permission from Tenovi. All trademarks are owned by or licensed to Tenovi, Co. unless otherwise noted.

Revision 05.01.2024

## **Remove Battery Cover**

Remove the battery cover on the back of the scale, and insert the 4 AAA batteries.






7

2

### Pairing your Scale & Gateway

With the gateway plugged in, press the back button on the scale to turn it on. Once the lights come on, press the button again and hold down for five seconds to trigger pairing mode. A blinking bluetooth symbol will appear on the scale screen. Once paired, the bluetooth symbol will stop blinking and appear with a box around it. The gateway will also beep once the pairing has been completed. You only need to perform this step once.



# Properly set up


Step on the scale and remain standing until your weight is displayed on the screen. Your weight measurement will automatically be sent to the Gateway.





**Scale Placement** 

Place the scale on a hard, even surface. Avoid using the device on carpet.



- Place your scale on a flat and hard surface.
- Do NOT place the scale on carpet or soft surface.

4

#### Take a measurement

When the measurement concludes, the Gateway will beep and the LED ring will turn green, indicating that you have properly taken a measuement, and that measurement was successfully transmitted.



